



ABB VISION ELSTER A1700 DISPLAY SEQUENCE & READING SHEET

The Elster A1700 electronic meter is also known as the 'Vision' meter. It has an automatic scrolling electronic display. If your RM number is 548, 549, 645, 647 or 650 this is the meter type you may have. The RM number is located at the bottom left hand side of the meter. The display changes every 9 seconds illustrating 20 different information panels.

CURRENT REGISTER VALUES

SEQUENCE



HISTORICAL REGISTER VALUES

