



# ISKRA MT173

If your RM number is 649 or 552 this is the meter type you may have. The RM number is located at the bottom left hand side of the meter. This meter may have an auto scroll feature that changes screens automatically. Press the button only if the meter has no auto scroll.

- |   |  |                                     |    |  |  |
|---|--|-------------------------------------|----|--|--|
| 1 | <br><small>T1 T2 RED PD DRO FF SET</small> | Current Date<br>(dd.mm.yy)          | 8  | <br><small>T1 T2 RED PD DRO FF SET</small> | MD2 Occurred End<br>Time (hh:mm:ss)              |
| 2 | <br><small>T1 T2 RED PD DRO FF SET</small> | Current Time<br>(hh:mm:ss)          | 9  | <br><small>T1 T2 RED PD DRO FF SET</small> | Rising Demand<br>(% 15min Elapsed<br>-- 0.000kW) |
| 3 | <br><small>T1 T2 RED PD DRO FF SET</small> | MD1 Normal kW<br>(08:00-21:00 GMT)  | 10 | <br><small>T1 T2 RED PD DRO FF SET</small> | Day kWh (08:00-<br>23:00 GMT)                    |
| 4 | <br><small>T1 T2 RED PD DRO FF SET</small> | MD1 Occurred Date<br>(dd.mm.yy)     | 11 | <br><small>T1 T2 RED PD DRO FF SET</small> | Night kWh (23:00-<br>08:00 GMT)                  |
| 5 | <br><small>T1 T2 RED PD DRO FF SET</small> | MD1 Occurred End<br>Time (hh:mm:ss) | 12 | <br><small>T1 T2 RED PD DRO FF SET</small> | Total Q1 Reactive<br>kVAh                        |
| 6 | <br><small>T1 T2 RED PD DRO FF SET</small> | MD2 Peak kW<br>(17:00-19:00 GMT)    | 13 | <br><small>T1 T2 RED PD DRO FF SET</small> | Total 24hr kWh                                   |
| 7 | <br><small>T1 T2 RED PD DRO FF SET</small> | MD2 Occurred Date<br>(dd.mm.yy)     | 14 | <br><small>T1 T2 RED PD DRO FF SET</small> | Back to Display 1                                |